

# PLEASE READ THE FOLLOWING PRIOR TO OPERATION OF THIS EQUIPMENT!

The following are basic safety precautions to understand when operating this Excavator. It is **NOT** intended to be a complete list of safety precautions. Please review the Operator Manual prior to operation. If one is not on the machine, contact All Star Rents and we will supply one to you.

## Basic Operation & Safety Requirements




This symbol means: **Attention! Be Alert! Your safety is involved!** The safety alert symbols found on decals and in the Operator Manual alert you to potential safety hazards. Obey all safety messages with this symbol to avoid possible injury or death.

Other similar symbols: **▲WARNING** **▲DANGER** **▲CAUTION**



Refer to the Operator Manual for any operational or safety questions you may have. Contact All Star Rents prior to operation if one is not located on the machine.



Use caution when operating on uneven terrain. Avoid any slopes where the machine could fall over. When travelling up or down slopes, keep the bucket on the uphill side and just above ground level. Avoid side hill work (downhill to left or right as opposed to in front or behind), as this is the most common cause of overturning. Understand that “soft”, rocky or frozen ground conditions can allow tractor to shift and tilt. **Keep the bucket or any implement on the tractor at the lowest possible position!** Any damage as a result of a machine tipping off either track is not covered by the Equipment Protection Plan.



Always fasten your seat belt and follow other precautions that keep you inside the ROPS (protection cage). Failing to do so could allow ejection from this protective area result in death or injury including the tractor crushing you.



**NEVER** allow riders anywhere on the machine!



Avoid backover accidents. Before moving machine, check surroundings. Maintain a safe distance from bystanders at all times. Bucket and digging arm present a crushing and impact danger.



Avoid contact with any buried gas lines, cables, water lines, etc. Call 811 to have area inspected prior to operation.



Use special care when lifting objects. Never use to lift people. Do not exceed lift capacity as this may cause the machine to tip over resulting in damage, injury or death. Use proper rigging to attach and stabilize loads.



Contact All Star Rents immediately if you have any problems with the machine. **DO NOT** attempt to repair, upright or start the machine if it has tipped over. Doing so could result in further injury or damage to the equipment. Call 911 first if serious injury as occurred while operating the tractor.

## All Star Rents Toll Free: 866-ALL STAR